



The GBK-Plus and GFK-Plus bench and floor checkweighing scales are designed to stand up to the demands of rigorous industrial applications. With a backlit, easy-to-read LCD, the large, 1.6"/40mm display and capacity tracker. Checkweighing is speedy with GBK-Plus and GFK-Plus, as their displays change color to quickly indicate if the sample is under (yellow), over (red) or within (green) preset limits. The advanced, full-numeric keypad simplifies checkweighing limits entry, while freely selectable sample sizes (as well as an impressive 1:1,600,000 internal counting resolution) make parts counting quick, easy and accurate. The grade 304 stainless steel pan provides an ample weighing surface. A pillar is standard with both GBK-Plus and GFK-Plus, so the indicator can be mounted if required.

Advanced user interface with smart features for versatile operation



Features

- Color-changing backlight in checkweighing mode to show if under, over or within acceptable limits
- Large, 40mm-high easy to read digits on a bright background
- Full numeric keypad for quick and easy entering of check weighing limits
- Capacity tracker built into display for easily monitoring possible overloads
- Solid ABS housing is durable for industrial use
- Selectable language for printing
- Rechargeable battery included for operation almost anywhere
- Hold function freezes the displayed weight, allowing time to elapse without losing the result
- Auto power-off to save energy
- Memory accumulation totals results
- Optional USB interface simplifies data communication
- RS-232 interface provides speedy connection to computers and printers
- External calibration allows for verification and adjustment with weights
- Selectable digital filtering for animal/dynamic weighing enables consistent results for moving subjects
- Wall-mount bracket for placing indicator on vertical surface
- 1:1,600,000 Internal counting resolution for precise results

Applications

- Weighing
- Checkweighing
- Percentage weighing
- Dynamic / animal weighing
- Net total weighing
- Check counting
- Parts counting
- Accumulation

About ADAM:

For more than 50 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Product Details

Model	GBK-Plus 8	GBK-Plus 16	GBK-Plus 32	GBK-Plus 60	GBK-Plus 120	GFK-Plus 75H	GFK-Plus 75	GFK-Plus 150H	GFK-Plus 150	GFK-Plus 300	GFK-Plus 600
Capacity	16lb / 8kg	35lb / 16kg	70lb / 32kg	130lb / 60kg	260lb / 120kg	165lb / 75kg		330lb / 150kg		660lb / 300kg	1320lb / 600kg
Readability	0.0002lb / 0.1g	0.001lb / 0.5g	0.002lb / 1g	0.005lb / 2g	0.01lb / 5g	0.002lb / 1g	0.01lb / 5g	0.005lb / 2g	0.02lb / 0.01kg	0.05lb / 0.02kg	0.1lb / 0.05kg
Weighing Units	g, kg, lb, oz, lb:oz										
Internal Counting Resolution	1:1,600,000										
Interface	RS-232, Optional USB										
Calibration	External										
Display	Backlit LCD with 1.6" / 40mm-high digits										
Power Supply	12VDC 800mA adapter, Internal rechargeable battery										
Operating Temperature	-10° to 40°C / 14° to 104°F										
Housing	ABS Plastic indicator with die-cast aluminum base										
Overall Dimensions (DxWxH)	11.8" x 20.1" x 26.8" / 300 x 510 x 680mm					15.7" x 24.4" x 33.9" / 400 x 620 x 860mm					23.6" x 37" x 35.4" / 600 x 940 x 900mm

Accessories

Item Number.....Description

- 3052010526 In-use wet cover
- 3074010266 RS-232 cable
- 3074010507 RS-232 to USB adapter
- 1120015779 ATP2 Thermal Printer
- 3126011263 ATP2 paper
- 3126011281 ATP2 paper (x10)
- 600002028 AdamDU Data Collection Program
- 700660290 Calibration certificate
- 1140013826 Roller deck (15.7" x 11.8")
- 1140013827 Roller deck (19.7" x 15.7")
- 1140013828 Roller deck (31.5" x 23.6")

Key Accessories



Roller Decks

Made from galvanized steel, roller decks are designed to easily fit on top of Adam Equipment platforms. When installed on bench and floor scale platforms, they allow parcels to be easily moved across them in two different orientations to accommodate front-to-back or side-to-side loading.



AdamDU Data Collection Program

Adam DU quickly collects information from up to eight Adam balances simultaneously. An easy-to-use interface with a main command window allows the user to view and manage data capture sessions.

Supplied by