LHS Crane Scales





LHS hanging scales offer shipping and production operations a strong and safe solution for weighing heavy loads. Ruggedly constructed to perform dependably in industrial settings, the LHS boasts cast aluminum magnesium indicator housing, chrome-plated steel hook, safety catch and oversized swivel shackle and bolt. The hook and shackle rotate, giving complete flexibility. A standard remote control allows safe and simple operation of the scale. Readings are shown on a bright-red LED display, making them visible in any lighting conditions. The hold function retains the reading on the display after the weight is removed from the scale, allowing time for the operator to record the value.

Suitable for weighing moderate loads, LHS delivers durability in a hanging scale







Features

- Bright LED display for easy viewing in most environments
- Rotating hook allows easy access while loading, then safely locks in place during weighing
- · Lightweight design simplifies transport and portability
- Remote control allows safe, hands-free operation
- · Rugged construction stands up to industrial use
- External calibration allows for verification and adjustment with weights
- Hold function freezes the displayed weight, allowing time to elapse without losing the result
- · Zero-tracking feature ensures display returns to zero reading
- · Programmable auto power-off to save energy

Applications

Weighing

About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment.

Adam provides the right balance of speed, performance and value.





Model	LHS 500	LHS 1500	LHS 2000
Capacity	500kg	1500kg	2000kg
Readability	0.1kg	0.2kg	0.5kg
Repeatability (S.D.)	0.1kg	0.2kg	0.5kg
Linearity (+/-)	0.2kg	0.4kg	1kg
Ultimate Overload Limit	750kg	2250kg	3000kg
Weighing Units	kg, lb, N		
Stabilisation Time (sec)	2		
Calibration	External calibration		
Display	LED with 25mm -high digits		
Power Supply	AC adapter / Internal rechargeable battery		
Operating Temperature	0° to 40°C		
Housing	Die-cast aluminum		
Overall Dim.	195x130x450mm (wxdxh)		
Net Weight	4.8kg		
Overload Limit	Adam Equipment Co Ltd, its directors, staff, owners and affiliated companies and organisations cannot be held liable for any resulting damage or injury sustained as a result of the machines being used in excess of their capacities and ultimate overload limits.		

Accessories

Item numberDescription700660288......Calibration certificate

Supplied by