LHS Crane Scales





LHS hanging scales offer shipping and production operations a strong and safe solution for weighing heavy loads. Ruggedly constructed to perform dependably in industrial settings, the LHS boasts cast aluminum magnesium indicator housing, chrome-plated steel hook, safety catch and oversized swivel shackle and bolt. The hook and shackle rotate, giving complete flexibility. A standard remote control allows safe and simple operation of the scale. Readings are shown on a bright-red LED display, making them visible in any lighting conditions. The hold function retains the reading on the display after the weight is removed from the scale, allowing time for the operator to record the value.

Suitable for weighing moderate loads, LHS delivers durability in a hanging scale



Features

- Bright LED display for easy viewing in most environments
- Rotating hook allows easy access while loading, then safely locks in place during weighing
- · Lightweight design simplifies transport and portability
- Remote control allows safe, hands-free operation
- Rugged construction stands up to industrial use
- · External calibration allows for verification and adjustment with weights
- Hold function freezes the displayed weight, allowing time to elapse without losing the result
- · Zero-tracking feature ensures display returns to zero reading
- · Programmable auto power-off to save energy

Applications

Weighing

About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

LHS Crane Scales



Model	LHS 1000a	LHS 3000a	LHS 4000a
Capacity	1000lb / 500kg	3000lb / 1500kg	4000lb / 2000kg
Readability	0.2lb / 0.1kg	0.5lb / 0.2kg	1lb / 0.5kg
Repeatability (S.D.)	0.2lb / 0.1kg	0.5lb / 0.2kg	1lb / 0.5kg
Linearity (+/-)	0.4lb / 0.2kg	1lb / 0.4kg	2lb / 0.001kg
Ultimate Overload Limit	1500lb / 750kg	4500lb /2250kg	6000lb / 3000kg
Weighing Units	kg, lb		
Stabilization Time (sec)	2		
Calibration	External calibration		
Display	LED with 1"/ 25mm -high digits		
Power Supply	AC adapter / Internal rechargeable battery		
Operating Temperature	0° to 40°C / 32° to 104°F		
Housing	Die-cast aluminum		
Overall Dim.	7.7"x5.1"x17.7" / 195x130x450mm (wxdxh)		
Net Weight	10.6lb / 4.8kg		
Overload Limit	Adam Equipment Co Ltd, its directors, staff, owners and affiliated companies and organizations cannot be held liable for any resulting damage or injury sustained as a result of the machines being used in excess of their capacities and ultimate overload limits.		

Accessories

Item numberDescription700660288.....Calibration certificate

Supplied by

www.adamequipment.com

Adam Equipment follows a policy of continuous improvement and reserves the right to change specification and pricing without notice. Adam Equipment's standard terms and conditions of sale apply. Errors and omissions excepted.