



The PTM platform scale features a low-profile base and integrated ramps on both sides, offering smooth transitions from the floor to the platform. Suitable for use in many settings, the PTM is ideal for checking the weight of wheelchair occupants, and loaded dollies, barrels and drums. Its chequer plate surface provides good grip and a solid, steady weighing area. Handles and wheels enable easy portability in a warehouse or medical facility. Combine the PTM with the GK indicator or AE 403 indicator for a range of features and functions. The GK indicator allows a numeric tare value to be entered, while the AE 403 is IP67 rated for harsh environments.

Low-profile base and easy-access ramps for warehouses or medical use



Features

- Adjustable levelling feet help optimise setup
- Built-in ramps on each side enable easy access
- Chequered plate surface for added grip
- Heavy-duty rubber feet ensure stability of unit
- Integrated wheels permit easy movement
- Three-meter load cell cable
- Rugged construction stands up to industrial use
- Ramps allow easy access for wheelchair use

Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Dynamic / animal weighing



AE 403 Indicator



GK Indicator

About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	PTM 500	PTM 500 [GK]	PTM 500 [AE403]
Capacity	500kg	500kg	500kg
Readability	0.1kg	0.1kg	0.1kg
Repeatability (S.D.)	0.1kg	0.1kg	0.1kg
Linearity (+/-)	0.2kg	0.2kg	0.2kg
Excitation Voltage	5 to 10V		
Loadcells	4		
Pan Size	760x580mm		
Weighing Units	N/A	kg, lb, lb:oz, oz, N	g, kg, lb, lb:oz, oz, N, custom unit
Stabilization Time (sec)	2		
Interface	N/A	RS-232	
Calibration	N/A	External calibration	
Display	N/A	Backlit LCD with 20mm -high digits	Backlit LCD with 40mm -high digits
Power Supply	N/A	12VDC 800mA adapter / Internal rechargeable battery	
Operating Temperature	-10° to 40°C		
Housing	Mild steel base		
Cable Length	3M		
Overall Dim.	1020x803x75mm (wxdxh)		
Net Weight	35.5kg		

Accessories

Item number	Description
700400103.....	RS-232 cable
112001156.....	ATP thermal printer
3126011263.....	ATP thermal printer paper
3126011281.....	ATP thermal printer paper (pack of 10)
3074010266.....	RS-232 cable (null-modem)
3074010507.....	RS-232 to USB adapter (must order corresponding RS-232 cable)
600002028.....	Adam DU data collection program
700660288.....	Calibration certificate
2050013351.....	Indicator stand

Key Accessories



ATP thermal printer
Easy-to-use features combined with quick set-up equals a truly versatile thermal printer. A single push-button feed key and three easy-to-read LED indicators make operation simple.



Adam DU data collection program
Adam DU software connects a balance to the laboratory network, helping to achieve seamless data collection, transfer and analysis. DU features an easy-to-use interface with a main command window, allowing users to quickly collect information from up to eight Adam balances simultaneously using RS-232 or USB connections.

Supplied by