WBZ Washdown Retail Scales



The WBZ washdown retail scale is ideally suited for food preparation, outdoor markets, shops and agriculture facilities. With a streamlined design, the WBZ fits neatly on crowded counters or workbenches. WBZ features a stainless steel pan and an IP66-rated washdown housing for protection against dust and water. The easy-to-read backlit display shows weight, price per unit, and an oversized view of the total cost. Completely portable, the WBZ operates with an AC adapter or rechargeable battery pack. WBZ is approved and suitable for use in trade.

Portable and durable IP66-rated scale is a winner for price computing in retail locations





HEADAN

Features

- Vivid, backlit LCD easily visible in any lighting conditions
- Backlit LCD shows weight, unit price and total price, to provide the key information simultaneously
- Rear display mounted on the back of the scale lets customers see key data
- · Colour-coded keys facilitate quick recognition of the most frequently used buttons
- · Heavy-duty rubber feet ensure stability of unit
- Large, grade 304 stainless steel pan allows easy cleaning
- · Overload protection helps prevent damage to internal components
- Sealed keypad protects against dirt and spills
- · Solid ABS housing is durable for industrial use
- · External calibration allows for verification and adjustment with weights
- · Preset tare function speeds the process of repetitive weighing
- · Price displayed in choice of available currencies
- · Security password control prevents unauthorised access
- · Auto-clear function enables the last item to be reset each time the scale returns to zero
- Switchable between price per kg and price per 100g
- · Zero-tracking feature ensures display returns to zero reading
- IP66-rated for protection against water and dust
- AC adapter included
- Rechargeable battery included for operation almost anywhere
- · Programmable auto power-off to save energy

Applications

- Weighing
- Price computing

About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

www.adamequipment.com

WBZ Washdown Retail Scales



Model	WBZ 3	WBZ 6	WBZ 15
Capacity	3kg	6kg	15kg
Readability	1g	2g	5g
Repeatability (S.D.)	1g	2g	5g
Linearity (+/-)	2g	4g	10g
Pan Size	210x173mm		
Weighing Units	kg		
Stabilisation Time (sec)	2		
Calibration	External calibration		
Display	Backlit LCD with 16mm -high digits		
Power Supply	12VDC 50/60Hz 800mA adapter / Internal rechargeable battery		
Operating Temperature	-10° to 40°C		
Housing	ABS plastic		
Overall Dim.	231x265x153mm (wxdxh)		
Net Weight	3.3kg		
Approvals	EC type approved: T7476 / NRCS approved: SA1460		

Accessories

Item number	Description
303200002	In-use cover (pack of 10)
303200003	In-use cover (pack of 20)
303209190	In-use cover
700660290	Calibration certificate
303149759	Vegetable Scoop (complete with fitting to scale)
303147960	Small scoop (complete with fitting to scale)
303147961	Medium scoop (complete with fitting to scale)

Key Accessories



In-use cover

In-use covers provide an easy and affordable way to help keep the balance clean and protected.



Vegetable Scoop Metal scoops are designed to make portioning and food measurement easy. Three sizes available, small, medium and large.

Supplied by

www.adamequipment.com

Adam Equipment follows a policy of continuous improvement and reserves the right to change specification and pricing without notice. Adam Equipment's standard terms and conditions of sale apply. Errors and omissions excepted.